

Model: AX-88
Device Type: Audio Switcher
Control System:



GENERAL INFORMATION	
SUMMARY:	Controls volume, input selection, bass, treble, subwoofer outputs, and delay.
GENERAL NOTES:	<p>This device is equipped with a LAN port. However, only the RS-232 port provides full control of the AX-88. This module is for RS-232 control only.</p> <p>All inputs/outputs with names surrounded by square braces are optional, and do not need to have signals defined on them.</p>
CRESTRON HARDWARE REQUIRED:	2-Series or 3-Series Processor with available RS-232 COM Port.
SETUP OF CRESTRON HARDWARE:	RS232 Baud: 9600 Parity: None Data Bits: 8 Stop Bits: 1 Flow Control: None
AX-88 SETUP:	<p>For standard setup, all DIP switches on the back of the AX-88 should be in the On position. See manual for other possible configurations.</p> <p><i>ID must be 0 (Switches 1-5 "On")</i></p>
CABLE:	CNSP-121

CONTROL		
From_Device	S	Serial information returned from device via a 2-way com port. This must be connected as two-way communication is required.
Mute-1 through Mute-8 , Mute-All	D	Mutes the corresponding output as long as the input is high. When the input goes low, audio resumes. High/1 (rising edge) = Mute output Low/0 (falling edge) = Resume output. Mute-All affect all outputs simultaneously.
Mute-On-1 through Mute-On-8 , Mute-On-All Mute-Off-1 through Mute-Off-8 Mute-Off-All	D	Pulse to mute or unmute the corresponding outputs. High/1 (rising edge) = Mute/unmute; Low/0 = No effect
Src-for-out-1 through Src-for-out-8 , Src-for-all	A	Selects the input to be switched to the corresponding output. Valid values are 0 - 8d. 0d = No source. Src-for-all affects all outputs simultaneously.
Volume-1 through Volume-8 , Volume-All	A	Sets the volume level of the corresponding output. Valid values are 0% (-78.5db) to 100% (0db) Volume-All affects all outputs simultaneously.
Volume-Up-1 through Volume-Up-8 , Volume-Up-All Volume-Down-1 through Volume-Down-8 , Volume-Down-All	D	Pulse to raise or lower the volume level of the corresponding outputs. These inputs incorporate a press-hold functionality where the volume will continue to raise/lower as long as the input is high.
Subwoofer-1 through Subwoofer-8 , Subwoofer-All	A	Sets the subwoofer level of the corresponding output. (150 Hz lowpass filter) Valid values are 0% (-37.5db) to 100% (0db) Subwoofer-All affects all outputs simultaneously.

CONTROL		
<p>Subwoofer-Up-1 through Subwoofer-Up-8, Subwoofer-Up-All</p> <p>Subwoofer-Down-1 through Subwoofer-Down-8, Subwoofer-Down-All</p>	D	<p>Pulse to raise or lower the Subwoofer level of the corresponding outputs.</p> <p>These inputs incorporate a press-hold functionality where the Subwoofer will continue to raise/lower as long as the input is high.</p>
<p>Bass-1 through Bass-8, Bass-All</p>	A	<p>Sets the bass level of the corresponding output relative to 50%. A value of 50% signifies a flat bass level corresponding to 0db.</p> <p>Valid values are 0% (-14db) to 100% (+14db).</p> <p>Inputs default to 50% (0db) and can be left undefined.</p> <p>Bass-All affects all outputs simultaneously.</p>
<p>Bass-Up-1 through Bass-Up-8, Bass-Up-All</p> <p>Bass-Down-1 through Bass-Down-8, Bass-Down-All</p>	D	<p>Pulse to raise or lower the Bass level of the corresponding outputs.</p> <p>These inputs incorporate a press-hold functionality where the Bass will continue to raise/lower as long as the input is high.</p>
<p>Treble-1 through Treble-8, Treble-All</p>	A	<p>Sets the treble level of the corresponding output relative to 50%. A value of 50% signifies a flat treble level corresponding to 0db.</p> <p>Valid values are 0% (-14db) to 100% (+14db).</p> <p>Inputs default to 50% (0db) and can be left undefined.</p> <p>Treble-All affects all outputs simultaneously.</p>
<p>Treble-Up-1 through Treble-Up-8, Treble-Up-All</p> <p>Treble-Down-1 through Treble-Down-8, Treble-Down-All</p>	D	<p>Pulse to raise or lower the Treble level of the corresponding outputs.</p> <p>These inputs incorporate a press-hold functionality where the Treble will continue to raise/lower as long as the input is high.</p>
<p>Delay-1 through Delay-8, Delay-All</p>	A	<p>Sets the Lip Sync delay of the corresponding output.</p> <p>Valid values are (AX-88 adjusts in increments of 5): 0d = 0ms (no delay) to 1000d = 1000 ms (1 sec delay.)</p> <p>Delay-All affects all outputs simultaneously.</p>

CONTROL		
Delay-Up-1 through Delay-Up-8, Delay-Up-All Delay-Down-1 through Delay-Down-8, Delay-Down-All	D	Pulse to raise or lower the Delay level of the corresponding outputs. These inputs incorporate a press-hold functionality where the Delay will continue to raise/lower as long as the input is high.
Poll-Mute, Poll-Src-For-Output, Poll-Volume, Poll-Subwoofer-Volume, Poll-Bass, Poll-Treble, Poll-Delay	D	The feedback outputs are updated when changes are made from the inputs on this module. However, the AX-88 does not provide feedback when changes are made from its front panel. If you want to keep the control system in sync with the front panel of the AX-88, you may use these inputs to poll Mute Status, Volume Level, Source For Output, etc., periodically as needed.

FEEDBACK		
To_Device	S	Serial information sent to device via a 2-way com port.
Mute-1_Fb through Mute-8_Fb	D	Indicates the current mute status for the corresponding output. The output remains high as long as mute is active. When low, this indicates audio has resumed. High/1 = Mute is On. Low/0 = Mute is Off.
Src-for-out-1_fb through Src-for-out-8_fb	A	Reports the currently active source for the corresponding output.
Volume-1_fb through Volume-8_fb	A	Reports the volume level as a percentage from 0% to 100%.
Subwoofer-1_fb through Subwoofer-8_fb	A	Reports the current subwoofer level of the corresponding output.
Bass-1_fb through Bass-8_fb	A	Reports the bass level of the corresponding output relative to 50%.
Treble-1_fb through Treble-8_fb	A	Reports the treble level of the corresponding output relative to 50%.
Delay-1_fb through Delay-8_fb	A	Reports the Lip Sync delay of the corresponding output 0 - 1000ms.

Copyright © 2015 Zigen Co., Ltd. All rights reserved.

No part of this document may be reproduced in any form or by any means without written permission from the product manufacturer. Changes are periodically made to the information in this document. They will be incorporated in subsequent editions. The product manufacturer may make improvements and /or changes in the product described in this document at any time.

All the registered trademarks referred in this manual belong to their respective owners.